


## © Solder Instruction

- 1. Cable should be prepared for soldering. The cable/wires must be pretinned.
- 2. Insert cable/wire into solder cup.
- 3. Operate the soldering iron at 350°C, 50 Watt max. and use a pencil tip.
- 4. Apply some solder to the solder tip of the soldering iron.
- 5. Put tip to wire in solder cup.
- 6. After 1 second bring in solder.
- 7. Heat for 3 seconds longer. Do not heat contact more than 4 seconds in total.
- 8. Remove soldering iron.
- 9. Wait until solder gets rigid again.
- 10. Do not solder adjacent contacts consecutively, alternate position within the connector to minimize heat build up.

## RECOMMENDED PANEL CUT-OUT



DRAWING MAY NOT BE COPIED OR ODUCED IN ANY WAY, AND MAY NOT SSED ON TO A THIRD PARTY WITHOUT	Т	GmbH	HAIND					tolerance			scale: 4:1
	.nor	<u>ဗ</u> ြဲ   ဗြဲ									material: SEE SHEET 1
	NI P	CONEC	ຼັດ [							dim. in mm	
	₩∑∠	유 당   년	5						date	name	title:
	E CO AND PAR	읽	DKAWING					drawn	23.09.14	Lehmenkühler	RECOMMENDED PANEL CUT-OUT
	OT BI WAY, HIRD							appd.	26.01.15	Fischer	D-SUB FEMALE 25pos. SOLDER CUP
	AY NC ANY V O A TH SION.		<u> </u>					norm			with closed 4-40 UNC thread
	M P P S		¥ [					d-old			dwg no: DIN-
	WIN CED D Of		AL.	1 x c	Ä5827	25.09.15	Unkrüer	_	45 =		15K1A1539 A3
	DRA ODU ASSE	WNERSHIP	<u> </u>	а	Original						15K1A1538
	E E E	₹   {		rev	description	data	name		7/1	<b>71.</b>	nart no: QEE QUEET 1