



ASSEMBLY INSTRUCTIONS:

- 1) Install lock bracket (Item 3) using self tapping screws (Item 4) into existing holes on side.
- 2) Install hinges (Item 2) on door (Item 1), ensure hinge pins are located with bent arm at the top.
- 3) Hinges are designed to simply "Snap" into cabinet frame. Push firmly to ensure hinges snap in fully.

| PARTS LIST | | |
|------------|-----------------------------|-----|
| ITEM No. | DESCRIPTION | QTY |
| 1 | PERFORATED DOOR | 1 |
| 2 | SNAP IN HINGE | 2 |
| 3 | LOCK BRACKET | 1 |
| 4 | 8-32 X 3/8" SELF TAP SCREWS | 2 |

TOOL BOX



Phillips
Screw Driver



**HAMMOND
MANUFACTURING™**
ELECTRONICS GROUP

visit our website @ www.hammondmfg.com